

Lip Glaze

PHASE	TRADE NAME	INCI NAME	SUPPLIER NAME	w/w %
A	ClearSyn 300	Hydrogenated Polydecene	Sandream Specialties	q.s.
A	PureSyn™ 4	Hydrogenated Poly (C6-14 Olefin)	Sandream Specialties	20.0
A	NOO	Octyldodecyl Oleate	Sandream Specialties	8.0
A	Microcrystalline Wax SP-16WP	Microcrystalline Wax	Strahl & Pitsch	4.00
A	Fermentoil Avocado	Candida Bombicola/Glucose/Methyl Rapeseedate Ferment (and) Persea Gratissima (Avocado) Oil	Access Ingredients	3.00
B	Vitamin E Acetate	Tocopheryl Acetate	Sandream Specialties	1.00
<i>Majestic Watermelon (224-2A)</i>				
C	Majestic Watermelon	Mica, Red 7 Lake	Sandream Specialties	1.00
C	Flavor Natural Watermelon	Flavor	Making Cosmetics	0.50
<i>Lavender Lemonade (224-2B)</i>				
C	Majestic Plum	Mica, Manganese Violet	Sandream Specialties	1.50
C	Majestic Coconut	Mica, Titanium Dioxide	Sandream Specialties	0.60
C	Majestic Watermelon	Mica, Red 7 Lake	Sandream Specialties	0.20
C	Lavender Lemonade Flavor Oil	Flavor	Bramble Berry	0.50
<i>Pineapple Mango (224-2C)</i>				
C	Majestic Mango	Mica, Yellow 5 Lake	Sandream Specialties	1.00
C	Pineapple Flavor Oil	Flavor	Bramble Berry	0.50

Procedure:

1. Add Phase A one by one to the main vessel and begin heating to 85°C, mix until uniform and homogenous.
2. Remove batch from heat and cool to 50°C.
3. Add Phase B to the main vessel and mix until uniform.
4. Add Phase C one by one to the main vessel and mix until uniform and homogenous.